

Cal 9230M1


(9230 / 0005)



13 1/4'''

30.6 mm

H. 4.20



Multifunction

12h



24 hours
by hand

9h



Day by
hand

6h



Dual Time

6h



Day and
night
indication

3h



Date by
window









Strong
motor


In conformity with RoHS standard



ISASPECIALITY

OBJECT	ILLUSTRATION	PROCEDURE	INFORMATION
Preparation			
Visual checking		<ol style="list-style-type: none"> 1) Check the dial. 2) Check the hands. 3) Check the case, case back and glass. 4) Check the hand setting stem. 	No scratches, no dust, no finger spots, no discoloration great flatness / straightness.
Dial fitting		<ol style="list-style-type: none"> 1) Pull the crown to position 3 to stop the movement. 2) Remove all the plastic hands. 3) Fit and hold the dial. 	Use the movement holder TRT01-84 to maintain the movement during hands fitting. TRT01-84 
Indexing date and second time zone		<ol style="list-style-type: none"> 1) Turn the crown clockwise until the date jump. 2) Press the push button B at 4H for indexing the day/night disk on a median position (limit day/night at 12H). 	
24h hand fitting		<ol style="list-style-type: none"> 1) Set the 24h hand onto the date counter at 12h. 2) Check height and flatness of the hand. 	
Hour, minute and second hands fitting		<ol style="list-style-type: none"> 1) Set the hour, minute and second hands on the center. 2) Check height and flatness of hands. 	

OBJECT	ILLUSTRATION	PROCEDURE	INFORMATION
Day and second time zone hands fitting		<ol style="list-style-type: none"> 1) Set the day hand onto the small counter at 9h. 2) Set the second time zone hand onto the small counter at 6h. Index this hand on the position 6h. 3) Check flatness and height of all hands. 	
Hand-setting stem		<ol style="list-style-type: none"> 1) Remove the hand-setting stem using the holder annexed. 2) Cut it at the length wanted and stick the crown. <p>Comment: Always remove the hand-setting stem on position 1.</p> <p>The movement is ready to be cased.</p>	<p>Use the movement holder TRT02-10</p> <p>TRT02-10</p> 
Casing			
Movement casing		Insert the movement in the case avoiding shocks in the middle.	Warning of the positions of hands to not touch the indexes of the dial.
Hand-setting stem		Insert the hand-setting stem after possible greasing of the axis.	
Casing ring		Insert the casing ring.	
Hand-setting stem checking		Check the straight rotation of the crown and the different positions of the hand-setting stem.	
Case back		Put the case back to close the watch-case.	

OBJECT	ILLUSTRATION	PROCEDURE	INFORMATION
Check and settings			
Cleanliness		Check the cleanliness of the watch (internal and external).	
Water-resistance		Check the water-resistance of the case if necessary.	
Hands synchronization and push-button checking		<ol style="list-style-type: none"> 1) Check the great synchronization between hands center and small counters 24h at (12h). 2) Check the great working of push-button B when setting a second time zone on the counter (6h). The hand has to do « jumps » of 1 hour involving also the disc night/day. 	
Date setting		<ol style="list-style-type: none"> 1) Pull the stem on position 2. 2) Turn the crown clockwise to adjust the date. 	Warning: The quick correction of the date is not available between « 21h00 » and « 00h30 ».

In conformity with RoHS standard

Doc. n° 0312203 - CG - B Up date : 27/02/2015 - Page 4